

4smarts

LOCATION FINDER SKYTAG PLUS



Works with
Apple Find My

Thank You 

for choosing a quality product from 4smarts

EN

1 Safety Instructions

Please read this user manual and the safety instructions carefully before first use. We assume no liability for damages caused by failure to comply with these instructions and safety guidelines.

1.1 General Safety Instructions

- Avoid strong vibrations, impacts, or excessive force. Protect the device from sunlight and rain during transportation.
- Store the device in a clean, cool, and dry place. Avoid direct sunlight and contact with corrosive substances.
- The device and its accessories contain small parts that can be hazardous if misused. Always keep them out of the reach of small children.
- Swallowable parts could pose a choking hazard. Ensure children or pets do not play with the device or its accessories to prevent damage or injuries.
- Do not drop the product or expose it to strong impacts, as this may cause damage and lead to malfunction.

1.2 Battery Precautions

- Overheating of the battery can cause an explosion.
- If the battery leaks, avoid contact of the liquid with skin and eyes. In case of direct contact, rinse immediately with clean water and seek medical attention.
- If a battery shows discoloration, deformation, abnormal heating, or other anomalies during use, charging, or storage, discontinue use and replace it with a new battery.
- Always dispose of the battery in accordance with regional disposal regulations. Do not dispose of it in household waste.

2 Technical Specifications

Bluetooth Version: 5.3

Range: Up to 50m (unobstructed)

Battery: CR2032 coin cell (210 mAh)

Standby: Up to 16 months

Power Supply: 3V / 3.3 mA

Frequency Range: 2400 MHz – 2483.5 MHz

Transmission Power: 4dBm

Speaker: 80-100 dB

Compatible with Apple Find My

Acoustic signal for preventing unauthorized tracking of individuals

3 Getting Started

The 4smarts SkyTag Plus is a practical device that helps you locate lost items more easily. Attach the SkyTag Plus to an object to monitor its location at any time.

Adding SkyTag Plus to Apple Find My:

- 1.Ensure your iPhone or iPad runs iOS 14.5 or later.
- 2.Enable Bluetooth on your device to connect to the SkyTag Plus.
- 3.Open the Find My app.
- 4.Select the "Add Item" option.
- 5.Place the SkyTag Plus near your iPhone (maximum 10 cm distance) to ensure detection.
- 6.Follow the on-screen instructions and tap "Connect" when prompted.
- 7.Assign a name to the SkyTag Plus to easily identify it in the app.
- 8.Once setup is complete, the SkyTag Plus will appear under the "Items" tab in the Find My app.

Location Monitoring

Use the Find My app at any time to check the location of your SkyTag Plus. This is especially helpful when searching for a misplaced item. The location will be displayed on a map.

Acoustic Search

If the SkyTag Plus is nearby but not visible, activate the sound signal via the app. The built-in speaker emits a sound at 80-100 dB, allowing you to locate the device quickly.

Customize Settings

Adjust the name or other settings of the SkyTag Plus in the Find My app to suit your preferences.

Battery Status

The app displays the battery level of the SkyTag Plus, so you can replace it in a timely manner.

Resetting

If the SkyTag Plus is not linked to an Apple ID within ten minutes, it will disable Bluetooth transmission to conserve power. To reset, remove and reinsert the battery five times. A distinct startup sound indicates successful resetting. You can then repeat the pairing process.

Pairing with another Apple ID:

To pair the SkyTag Plus with another Apple device, first remove it from your Find My app. Go to the "Items" tab, select the SkyTag Plus, scroll to the bottom of the detail card, and choose "Remove Item." Then, follow the pairing instructions above to connect it to a different ID.

EN

4 Function Notes

Activating Lost Mode

You can enable "Lost Mode" on the SkyTag Plus to make it easier to find lost items.

- 1.Open the Find My app and select the added SkyTag Plus.
- 2.Tap "Lost" and follow the on-screen instructions.
- 3.Enter your phone number so others can contact you if they find your SkyTag Plus.
- 4.You will receive a push notification as soon as your SkyTag Plus is detected by a device within the "Find My" network.

Tracking Prevention

Your iOS device will alert you if a foreign SkyTag Plus remains near you for an extended period. If the device remains undetected, an alarm will sound to warn you. Note: You will not receive a notification if the SkyTag Plus is near its owner.

Privacy Protection

Only you can see the location of your SkyTag Plus. The device does not store location data or histories physically. All data transmissions within the "Find My" network are anonymous and encrypted. Neither Apple nor other users can view the identity or location of devices participating in the search.

5 Maintenance and Care

- Do not open the device; have it repaired by a professional.
- Avoid using harsh chemicals or cleaning agents.
- Use a clean, dry cloth for wiping.
- Check the battery regularly and replace it if necessary to ensure long-lasting operation.

6 Warranty

4smarts GmbH accepts no liability or warranty for damages resulting from improper installation, assembly, or use of the product, or failure to observe the user manual and/or safety instructions.

7 Environmental Protection Information



Electrical and electronic devices, as well as batteries, must not be disposed of with household waste. Consumers are legally obligated to return electrical and electronic devices, as well as batteries, to designated public collection points or the point of sale at the end of their service life.

EN

8 Service and Support

For defective products or issues during installation, please contact your retailer or the 4smarts Product Support team at: <http://www.4smarts.com/contact>.

Service Hotline: Monday–Friday, 9 AM–5 PM

Phone: +49(0)821 20708444

Email: customer-service@4smarts.com

9 Declaration of Conformity

Hereby, 4smarts GmbH declares that this product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. For further information and the full Declaration of Conformity under the RED Directive, please visit: www.4smarts.com.

*Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. To use the Apple Find My app to locate this item, the latest version of iOS, iPadOs, or macOS is recommended.

EN

1 Sicherheitshinweise

Bitte lies diese Bedienungsanleitung und die Sicherheitshinweise vor der ersten Inbetriebnahme sorgfältig durch. Für Schäden, die durch Nichtbeachtung dieser Anleitung und der Sicherheitshinweise entstehen, übernehmen wir keine Haftung.

1.1 Allgemeine Sicherheitshinweise

- Vermeide starke Vibrationen, Stöße oder Extrusion, schütze das Gerät vor Sonne und Regen während des Transports.
- Das Gerät sollte in einem sauberen, kühlen und trockenen Raum gelagert werden, direkte Sonneneinstrahlung und Kontakt mit ätzenden Substanzen vermeiden.
- Das Gerät und das Zubehör enthalten kleine Bauteile, die bei unsachgemäßem Umgang gefährlich sein können. Bewahre sie stets außerhalb der Reichweite von Kleinkindern auf.
- Verschlussbare Teile könnten Erstickungsgefahr verursachen. Achte darauf, dass Kinder oder Haustiere nicht damit spielen, um Schäden am Gerät oder Verletzungen zu vermeiden.
- Lass das Produkt nicht fallen und setze es keinen starken Stößen aus, um es nicht zu beschädigen, was zu einem Ausfall des Geräts führen kann.

1.2 Vorsichtsmaßnahmen für Batterien

- Eine Überhitzung der Batterie kann eine Explosion verursachen.
- Falls die Batterie ausläuft, vermeide den Kontakt von Haut und Augen mit der auslaufenden Flüssigkeit. Bei direktem Kontakt spüle bitte sofort mit klarem Wasser und begib dich zur ärztlichen Behandlung in ein Krankenhaus.
- Wenn eine Batterie während des Gebrauchs, des Aufladens oder der Aufbewahrung Verformungen, Verformungen, abnormale Erwärmung oder andere Anomalien aufweist, verwende sie bitte nicht mehr und ersetze sie durch eine neue Batterie.
- Entsorge die Batterie stets nach den regionalen Entsorgungsvorschriften und wirf sie nicht in den Hausmüll.

2 Technische Daten

Bluetooth-Version: 5.3

Reichweite: Bis zu 50 m (ohne Hindernisse)

Batterie: CR2032 Knopfzelle (210 mAh)

Standby: bis zu 16 Monate

Stromversorgung: 3V / 3.3 mA

Frequenzbereich: 2400 MHz – 2483.5 MHz

Übertragungsleistung: 4dBm

Lautsprecher: 80-100 dB

Kompatibel mit Apple Find My

Akustisches Signal zum Schutz vor unerlaubtem Tracking von Personen

3 Erste Schritte

Der 4smarts SkyTag Plus ist ein praktisches Gerät, das dir hilft, verlorene Gegenstände leichter zu finden. Wenn du den SkyTag Plus an einem Objekt befestigst, kannst du jederzeit den Standort dieses Objekts sehen.

Hinzufügen des SkyTag Plus zu Apple Wo ist?:

- 1.Stelle sicher, dass dein iPhone oder iPad iOS 14,5 oder höher nutzt.
- 2.Aktiviere Bluetooth auf deinem Gerät und stelle eine Verbindung zum SkyTag Plus her.
- 3.Öffne die Wo ist?-App.
- 4.Wähle die Option "Objekt hinzufügen".
- 5.Positioniere den SkyTag Plus in unmittelbarer Nähe deines iPhones (maximal 10 cm Abstand), damit er erkannt werden kann.
- 6.Folge den Anweisungen auf dem Bildschirm und tippe auf "Verbinden", sobald die Aufforderung erscheint.
- 7.Vergib einen Namen für den SkyTag Plus, um ihn in der App einfacher zu identifizieren.
- 8.Nach erfolgreicher Einrichtung wird der SkyTag Plus unter der Registerkarte "Objekte" in der Wo ist?-App angezeigt.

Standortüberprüfung

Prüfe mit der Wo ist?-App jederzeit, wo sich dein SkyTag Plus befindet. Dies ist besonders hilfreich, wenn du einen verlorenen Gegenstand suchst. Der Standort wird auf einer Karte angezeigt.

Akustische Suche

So findest du deinen SkyTag Plus in der Nähe, aber nicht sichtbar platziert haben, aktiviere in der App den Signalton. Der eingebaute Lautsprecher gibt einen Ton mit 80-100 dB von sich, sodass du den SkyTag leicht finden kannst.

Einstellungen personalisieren

Pass den Namen oder andere Einstellungen des SkyTag Plus in der Wo ist?-App an, um die Nutzung auf deine Bedürfnisse abzustimmen.

Batteriestatus

Die App zeigt dir den Batteriestand des SkyTag Plus an. So kannst du rechtzeitig eine neue Batterie einlegen.

Zurücksetzen

Sollte der SkyTag Plus innerhalb von zehn Minuten nicht mit einer Apple ID verknüpft werden, deaktiviert er die Bluetooth-Übertragung, um Energie zu sparen. Zum Zurücksetzen entferne und setze die Batterie fünfmal ein. Ein verändertes Einschaltgeräusch zeigt den erfolgreichen Reset an. Anschließend kannst du die Kopplung erneut durchführen.

Mit einer anderen Apple ID koppeln:

Wenn du den SkyTag Plus mit einem anderen Apple Gerät koppeln möchtest, entferne ihn zuerst aus deiner Wo ist? App. Gehe dazu zur Registerkarte "Objekte", tippe auf den Namen des SkyTag Plus, scrolle zum Ende der Detailkarte und wähle "Objekt entfernen". Anschließend kannst du den SkyTag Plus mit einer anderen ID koppeln, indem du die oben genannten Anweisungen befolgst.

4 Hinweise zur Bedienung

Verloren-Modus aktivieren

Du kannst den SkyTag Plus in den "Verloren-Modus" versetzen, um verlorene Gegenstände leichter wiederzufinden.

- 1.Öffne die Wo ist?-App und wähle den hinzugefügten SkyTag Plus aus.
- 2.Tippe auf "Verloren" und folge den Anweisungen in der App.
- 3.Gib deine Telefonnummer an, damit andere Personen dich kontaktieren können, wenn sie deinen SkyTag Plus finden.
- 4.Du erhältst eine Benachrichtigung per Push-Mitteilung, sobald dein SkyTag Plus von einem Gerät im "Wo ist?"-Netzwerk gefunden wird.

Schutz vor unerwünschtem Tracking

Dein iOS-Gerät erkennt, wenn sich ein fremder SkyTag Plus über längere Zeit in deiner Nähe befindet. In diesem Fall erhältst du eine Warnmeldung. Wenn der SkyTag Plus weiterhin unentdeckt bleibt, wird ein Alarmton abgespielt, um dich zu warnen. Hinweis: Du erhältst keine Benachrichtigung, wenn sich der SkyTag Plus in der Nähe seines Besitzers befindet.

Privatsphärenschutz

Nur du kannst den Standort deines SkyTag Plus sehen. Der SkyTag Plus speichert keine Standortdaten oder -verläufe physisch im Gerät. Alle Datenübertragungen im "Wo ist?"-Netzwerk sind anonym und verschlüsselt. Weder Apple noch andere Nutzer können die Identität oder den Standort von Geräten einsehen, die an der Suche beteiligt sind.

5 Wartung und Pflege

- Öffne das Gerät nicht und lass es nur von einem Fachmann reparieren.
- Verwende zur Reinigung keine scharfen Chemikalien, Reinigungsmittel oder ähnliches.
- Verwende zum Abwischen ein sauberes, trockenes Stofftuch.
- Kontrolliere die Batterie regelmäßig und tausche sie ggf. aus, um eine dauerhafte Funktion zu gewährleisten.

6 Gewährleistung

Die 4smarts GmbH übernimmt keinerlei Haftung oder Gewährleistung für Schäden, die aus unsachgemäßer Installation, Montage und unsachgemäßem Gebrauch des Produktes oder einer Nichtbeachtung der Bedienungsanleitung und /oder der Sicherheitshinweise resultieren.

7 Hinweise zum Umweltschutz



Elektrische und elektronische Geräte sowie Batterien dürfen nicht mit dem Hausmüll entsorgt werden. Der Verbraucher ist gesetzlich verpflichtet, elektrische und elektronische Geräte sowie Batterien am Ende ihrer Lebensdauer an den dafür eingerichteten, öffentlichen Sammelstellen oder an die Verkaufsstelle zurückzugeben.

8 Service und Support

Bei defekten Produkten oder Problemen während der Installation wende dich bitte an deinen Händler oder an die 4smarts Produktberatung auf: <http://www.4smarts.com/contact>

Service Hotline

Montag –Freitag: 9 –17h

+ 49(0)821 20708444

E-Mail: customer-service@4smarts.com

9 Konformitätshinweis

Hiermit erklärt die 4smarts GmbH, dass sich dieses Produkt in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 2014/53/EU befindet. Die Konformitätserklärung nach der RED Richtlinie findest du unter www.4smarts.com.

*Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended.

4smarts

Thanks for buying our product! We at 4smarts are sure it will serve you well. Follow us on social media for news, customer support and to win great prizes. See you there!



@4smarts_official



facebook.com/4smarts



linkedin.com/company/4smarts



All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.