


4smarts

LOCATION FINDER

SKYTAG DUOS



Thank You 
for choosing a quality product from 4smarts

1 Safety Instructions

1.1 General Safety Instructions

Please read this user manual and the safety instructions carefully before first use. We assume no liability for damages caused by failure to comply with these instructions and safety guidelines.

- Keep the device away from heat sources, direct sunlight, water, moisture, and any other liquids.
- Avoid strong vibrations, impacts, or excessive force. Do not drop the device or expose it to strong shocks.
- Store the device in a clean, cool, and dry place. Avoid contact with corrosive substances.
- Do not operate or charge the device if it has been exposed to water, moisture, or any other liquids.
- Do not use the device if it has been dropped or damaged in any way.
- Repairs should only be performed by qualified personnel. Improper repairs may pose serious safety risks.
- Use the device only for its intended purpose.
- The device and its accessories contain small parts that can pose a choking hazard.
- Keep the device and accessories out of reach of children and pets.
- This appliance is not a toy.
- Batteries (battery pack or installed batteries) must not be exposed to excessive heat such as sunshine, fire, or similar conditions.

1.2 Battery Precautions

- Overheating of the battery can cause an explosion.
- If the battery leaks, avoid contact of the liquid with skin and eyes. In case of direct contact, rinse immediately with clean water and seek medical attention.
- If a battery shows discoloration, deformation, abnormal heating, or other anomalies during use, charging, or storage, discontinue use and replace it with a new battery.
- Always dispose of the battery in accordance with regional disposal regulations. Do not dispose of it in household waste.

2 Technical Specifications

Wireless Version: 5.3

Wireless Name: Google: Air Device - Apple: SkyTagPlus

Range: Up to 50m (unobstructed)

Battery: CR2032 coin cell (210 mAh)

Standby: Up to 16 months

Power Supply: 3V / 3.3 mA

Frequency Range: 2400 MHz – 2483.5 MHz

Transmission Power: 4dBm

Speaker: 80-100 dB

Compatible with Apple Find My or Android Find Hub

Acoustic signal for preventing unauthorized tracking of individuals

3 Getting Started

Important Note on Using with Apple and Android

The 4smarts SkyTag Duos can be connected either to the Apple Find My network or to the Google Find Hub (Find My Device) network – **not both at the same time.**

If you wish to switch networks, you must first unlink the SkyTag Duos from the currently connected system:

- In the Apple Find My app: Items → [SkyTag Duos] → Remove Item
- In the Google Find My Device app: Device → Settings → Remove Device

Afterwards, you can reset the SkyTag Duos (press the button five times in quick succession, holding it for 5 seconds on the fifth press until a confirmation tone sounds) and then connect it to the other network.

The 4smarts SkyTag Duos is a practical device that helps you locate lost items more easily.

Attach the SkyTag Duos to an object to monitor its location at any time.


Battery Replacement

When you replace the battery, use a CR2032 coin cell and make sure the positive (+) side is facing up. Pro tip: Gently press and twist the latch to open the battery compartment. Make sure to close the compartment securely to ensure a stable connection.

ON/OFF button

The ON/OFF symbol on the front is used to activate and deactivate your SkyTag Duos.

- Short press: Switches the device on, accompanied by a start sound.
- Long press: Triggers two consecutive beeps to announce that the device is shutting down.



4 Operating Instructions under Apple Find My

Adding SkyTag Duos to Apple Find My:

1. Ensure your iPhone or iPad runs iOS 14.5 or later.
2. Activate your device's Bluetooth function so that the SkyTag Duos can be detected and connected.
3. Open the Find My app.
4. Select the "Add Item" option.
5. Turn on the SkyTag Duos by briefly pressing the on/off symbol on the front.
6. Place the SkyTag Duos near your iPhone (maximum 10 cm distance) to ensure detection.

7. Follow the on-screen instructions and tap "Connect" when prompted.
8. Assign a name to the SkyTag Duos to easily identify it in the app.
9. Once setup is complete, the SkyTag Duos will appear under the "Items" tab in the Find My app.

Location Monitoring

Use the Find My app at any time to check the location of your SkyTag Duos. This is especially helpful when searching for a misplaced item. The location will be displayed on a map.

Acoustic Search

If the SkyTag Duos is nearby but not visible, activate the sound signal via the app. The built-in speaker emits a sound at 80-100 dB, allowing you to locate the device quickly.

Customize Settings

Adjust the name or other settings of the SkyTag Duos in the Find My app to suit your preferences.

Battery Status

The app displays the battery level of the SkyTag Duos, so you can replace it in a timely manner.

Resetting

If the SkyTag Duos is not paired with an Apple ID within ten minutes, it automatically enters power-saving mode and ends the active connection. To reset, press the button five times consecutively and hold it on the fifth press for 5 seconds until you hear a confirmation sound. A distinct startup sound signals a successful reset. You can then repeat the pairing process.

Pairing with another Apple ID:

To pair the SkyTag Duos with another Apple device, first remove it from your Find My app. Go to the "Items" tab, select the SkyTag Duos, scroll to the bottom of the detail card, and choose "Remove Item." Then, follow the pairing instructions above to connect it to a different ID.

Activating Lost Mode

You can enable "Lost Mode" on the SkyTag Duos to make it easier to find lost items.

1. Open the Find My app and select the added SkyTag Duos.
2. Tap "Lost" and follow the on-screen instructions.
3. Enter your phone number so others can contact you if they find your SkyTag Duos.
4. You will receive a push notification as soon as your SkyTag Duos is detected by a device within the "Find My" network.

Tracking Prevention

Your iOS device will alert you if a foreign SkyTag Duos remains near you for an extended period. If the device remains undetected, an alarm will sound to warn you. Note: You will not receive a notification if the SkyTag Duos is near its owner.

Privacy Protection

Only you can see the location of your SkyTag Duos. The device does not store location data or histories physically. All data transmissions within the "Find My" network are anonymous and encrypted. Neither Apple nor other users can view the identity or location of devices participating in the search.

5 Operating Instructions under Android Find Hub

Adding the SkyTag Duos to Google Find Hub

1. Make sure your Android smartphone is running Android 9 or later.
2. Enable your device's Bluetooth and Location functions to establish the connection.
3. Open the Find Hub app.
4. Tap "Add new device" or "Pair tracker."
5. Turn on the SkyTag Duos by briefly pressing the on/off symbol on the front.
6. Hold the SkyTag Duos close to your smartphone (maximum distance 10 cm) so it can be detected.
7. A pop-up will appear; pair the "Air Device" displayed in it.
8. Follow the on-screen instructions and confirm the pairing.
9. Assign a name to your SkyTag Duos so you can easily identify it in the app.

Note: If the pop-up window does not appear, please check your internet and wireless connections or log out of the app and log back in again.

After successful setup, your SkyTag Duos will appear in the device list of the **Find My Device app.**

Pairing with another Google Account

If you want to connect your SkyTag Duos to another Google account, first remove it from the Find My Device app. Open the app and select your SkyTag Duos. Tap "Remove device." Then press the button five times in quick succession, holding it for about 5 seconds on the fifth press until a confirmation tone sounds. After that, you can pair the SkyTag Duos with another Google account by following the steps above again.

Activating Lost Mode

If you've lost your SkyTag Duos:

1. Open the Find My Device app and select the respective device.
2. Activate Lost Mode and optionally provide a phone number or email address.

You'll automatically receive a notification once your SkyTag Duos is detected by another device within the Find My Device / Find Hub network.

Protection Against Unwanted Tracking

Your Android device automatically detects if an unknown tracker stays near you for an extended period. In this case, you'll receive a warning notification. If the SkyTag Duos remains nearby, it will emit a sound alert to notify you.

Privacy Protection

Only you can see the location of your SkyTag Duos. The device does not store any location data locally. All data transmissions via the Google Find My Device network are encrypted and anonymized. Neither Google nor other users can access your identity or the exact location of your tracker.

6 Maintenance and Care

- Do not open the device; have it repaired by a professional.
- Avoid using harsh chemicals or cleaning agents.
- Use a clean, dry cloth for wiping.
- Check the battery regularly and replace it if necessary to ensure long-lasting operation.

7 Warranty

4smarts GmbH accepts no liability or warranty for damages resulting from improper installation, assembly, or use of the product, or failure to observe the user manual and/or safety instructions.

8 Environmental Protection Information



Electrical and electronic devices, as well as batteries, must not be disposed of with household waste. Consumers are legally required to return them to public collection points or retail outlets at the end of their service life. By recycling and disposing of them properly, you make an important contribution to environmental protection.

9 Service and support

For defective products or issues during installation, please contact your retailer or the 4smarts Product Support team at: <http://www.4smarts.com/contact>.

Service Hotline: Monday–Friday, 9 AM–5 PM

Phone: +49(0)821 20708444

Email: customer-service@4smarts.com

10 Declaration of Conformity

Hereby, 4smarts GmbH declares that this product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. For further information and the full Declaration of Conformity under the RED Directive, please visit: www.4smarts.com.

11 EU Data Act Notice

This product generates data during use (e.g. location, voice or status information). These data are accessible only to the user and are used solely for providing functionality. Processing takes place within the respective system, app or device. 4smarts has no access to these data.

12 Notice on Network Technologies and Trademark Rights

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended.

Use of the Works with Google Find My Device badge means that this product has been designed to work specifically with the Find My Device network and has been certified by the manufacturer to meet Google's network product specifications and requirements. Google is not responsible for the operation of this device or its compliance with safety and regulatory standards. Google, Android, and Find My Device are trademarks of Google LLC.

1 Sicherheitshinweise

Bitte lies diese Bedienungsanleitung und die Sicherheitshinweise vor der ersten Inbetriebnahme sorgfältig durch. Für Schäden, die durch Nichtbeachtung dieser Anleitung und der Sicherheitshinweise entstehen, übernehmen wir keine Haftung.

1.1 Allgemeine Sicherheitshinweise

- Halte das Gerät von Wärmequellen, direkter Sonneneinstrahlung, Wasser, Feuchtigkeit und anderen Flüssigkeiten fern.
- Vermeide starke Vibrationen, Stöße oder übermäßige Krafteinwirkung. Lass das Gerät nicht fallen und setze es keinen Erschütterungen aus.
- Bewahre das Gerät an einem sauberen, kühlen und trockenen Ort auf. Vermeide den Kontakt mit korrosiven Stoffen.
- Betreibe oder lade das Gerät nicht, wenn es mit Wasser, Feuchtigkeit oder anderen Flüssigkeiten in Kontakt gekommen ist.
- Verwende das Gerät nicht, wenn es heruntergefallen oder in irgendeiner Weise beschädigt ist. Reparaturen dürfen nur von qualifiziertem Fachpersonal durchgeführt werden.
- Unsachgemäße Reparaturen können ein erhebliches Sicherheitsrisiko darstellen. Verwende das Gerät ausschließlich für den vorgesehenen Zweck.
- Das Gerät und sein Zubehör enthalten Kleinteile, die bei unsachgemäßem Gebrauch eine Erstickungsgefahr darstellen können.
- Halte das Gerät und Zubehör von Kindern und Haustieren fern.
- Dieses Produkt ist kein Spielzeug.
- Batterien (Batteriepacks oder eingesetzte Batterien) dürfen keiner übermäßigen Hitze wie Sonneneinstrahlung, Feuer oder ähnlichen Einflüssen ausgesetzt werden.

1.2 Vorsichtsmaßnahmen für Batterien

- Eine Überhitzung der Batterie kann eine Explosion verursachen.
- Falls die Batterie ausläuft, vermeide den Kontakt von Haut und Augen mit der auslaufenden Flüssigkeit. Bei direktem Kontakt spüle bitte sofort mit klarem Wasser und begib dich zur ärztlichen Behandlung in ein Krankenhaus.
- Wenn eine Batterie während des Gebrauchs, des Aufladens oder der Aufbewahrung Verfärbungen, Verformungen, abnormale Erwärmung oder andere Anomalien aufweist, verwende sie bitte nicht mehr und ersetze sie durch eine neue Batterie.
- Entsorge die Batterie stets nach den regionalen Entsorgungsvorschriften und wirf sie nicht in den Hausmüll.

2 Technische Daten

Wireless-Version: 5.3
Wireless-Name: Google: Air Device - Apple: SkyTagPlus
Reichweite: Bis zu 50 m (ohne Hindernisse)
Batterie: CR2032 Knopfzelle (210 mAh)
Standby: bis zu 16 Monate
Stromversorgung: 3V / 3.3 mA
Frequenzbereich: 2400 MHz – 2483.5 MHz
Übertragungsleistung: 4dBm
Lautsprecher: 80-100 dB
Kompatibel mit Apple Find My oder Android Find Hub
Akustisches Signal zum Schutz vor unerlaubtem Tracking von Personen

DE

3 Erste Schritte

Wichtiger Hinweis zur Nutzung mit Apple und Android

Der 4smarts SkyTag Duos kann entweder mit dem Apple „Wo ist?“-Netzwerk oder mit dem Google Find Hub (Find My Device)-Netzwerk verbunden werden – nicht gleichzeitig mit beiden. Wenn du das Netzwerk wechseln möchtest, musst du den SkyTag Duos zuerst vom aktuell genutzten System entkoppeln:

- In der Apple “Wo ist?”-App unter Objekte → [SkyTag Duos] → Objekt entfernen
- In der Google Find My Device-App unter Gerät → Einstellungen → Gerät entfernen

Anschließend kannst du den SkyTag Duos durch Zurücksetzen (Taste fünfmal kurz drücken, beim fünften Mal 5 Sekunden halten, bis ein Signalton erklingt) und ihn danach mit dem anderen Netzwerk verbinden.

Der 4smarts SkyTag Duos ist ein praktisches Gerät, das dir hilft, verlorene Gegenstände leichter zu finden. Wenn du den SkyTag Duos an einem Objekt befestigst, kannst du jederzeit den Standort dieses Objekts sehen.


Batteriewechsel

Wenn du die Batterie austauschst, verwende eine CR2032-Knopfbatterie und achte darauf, dass die positive (+) Seite nach oben zeigt. Profi-Tipp: Drücke und drehe vorsichtig den Verriegelungsschalter, um das Batteriefach zu öffnen. Achte darauf, das Fach sicher zu schließen, um eine stabile Verbindung zu gewährleisten.

Ein-/Aus Schaltknopf

Das Ein-/Aus-Symbol auf der Vorderseite dient zum Aktivieren und Deaktivieren deines SkyTag Duos.

- Kurzes Drücken: Schaltet das Gerät ein, begleitet von einem Startsound.
- Langes Drücken: Löst zwei aufeinanderfolgende Pieptöne aus, die das Herunterfahren des Geräts ankündigen.



Power

4 Hinweise zur Bedienung unter Apple Find My

Hinzufügen des SkyTag Duos zu Apple Wo ist?:

1. Stelle sicher, dass dein iPhone oder iPad iOS 14.5 oder höher nutzt.
2. Aktiviere die Bluetooth-Funktion deines Geräts, damit der SkyTag Duos erkannt und verbunden werden kann.
3. Öffne die Wo ist?-App.
4. Wähle die Option "Objekt hinzufügen".
5. Schalte den SkyTag Duos durch kurzes Drücken des Ein-/Aus-Symbols auf der Vorderseite ein.
6. Positioniere den SkyTag Duos in unmittelbarer Nähe deines iPhones (maximal 10 cm Abstand), damit er erkannt werden kann.

DE

7. Folge den Anweisungen auf dem Bildschirm und tippe auf "Verbinden", sobald die Aufforderung erscheint.
8. Vergib einen Namen für den SkyTag Duos, um ihn in der App einfacher zu identifizieren.
9. Nach erfolgreicher Einrichtung wird der SkyTag Duos unter der Registerkarte "Objekte" in der Wo ist?-App angezeigt.

Standortüberprüfung

Prüfe mit der Wo ist?-App jederzeit, wo sich dein SkyTag Duos befindet. Dies ist besonders hilfreich, wenn du einen verlorenen Gegenstand suchst. Der Standort wird auf einer Karte angezeigt.

Akustische Suche

Solltest du deinen SkyTag Duos in der Nähe, aber nicht sichtbar platziert haben, aktiviere in der App den Signalton. Der eingebaute Lautsprecher gibt einen Ton mit 80-100 dB von sich, sodass du den SkyTag leicht finden kannst.

Einstellungen personalisieren

Passen den Namen oder andere Einstellungen des SkyTag Duos in der Wo ist?-App an, um die Nutzung auf deine Bedürfnisse abzustimmen.

Batteriestatus

Die App zeigt dir den Batteriestand des SkyTag Duos an. So kannst du rechtzeitig eine neue Batterie einlegen.

Zurücksetzen

Wenn der SkyTag Duos innerhalb von zehn Minuten nicht mit einer Apple ID gekoppelt wird, wechselt er automatisch in den Energiesparmodus und beendet die aktive Verbindung. Zum Zurücksetzen drücke die Taste fünf Mal hintereinander und halte sie beim 5. Mal für 5 Sekunden lang gedrückt, bis ein Bestätigungston ertönt. Ein verändertes Einschaltgeräusch zeigt den erfolgreichen Reset an. Anschließend kannst du die Kopplung erneut durchführen.

Mit einer anderen Apple ID koppeln

Wenn du den SkyTag Duos mit einem anderen Apple Gerät koppeln möchtest, entferne ihn zuerst aus deiner Wo ist? App. Gehe dazu zur Registerkarte "Objekte", tippe auf den Namen des SkyTag Duos, scrolle zum Ende der Detailkarte und wähle "Objekt entfernen". Anschließend kannst du den SkyTag Duos mit einer anderen ID koppeln, indem du die oben genannten Anweisungen befolgst.

Verloren-Modus aktivieren

Du kannst den SkyTag Duos in den "Verloren-Modus" versetzen, um verlorene Gegenstände leichter wiederzufinden.

1. Öffne die Wo ist?-App und wähle den hinzugefügten SkyTag Duos aus.
2. Tippe auf "Verloren" und folge den Anweisungen in der App.
3. Gib deine Telefonnummer an, damit andere Personen dich kontaktieren können, wenn sie deinen SkyTag Duos finden.
4. Du erhältst eine Benachrichtigung per Push-Mitteilung, sobald dein SkyTag Duos von einem Gerät im "Wo ist?"-Netzwerk gefunden wird.

Schutz vor unerwünschtem Tracking

Dein iOS-Gerät erkennt, wenn sich ein fremder SkyTag Duos über längere Zeit in deiner Nähe befindet. In diesem Fall erhältst du eine Warnmeldung. Wenn der SkyTag Duos weiterhin unentdeckt bleibt, wird ein Alarmton abgespielt, um dich zu warnen. Hinweis: Du erhältst keine Benachrichtigung, wenn sich der SkyTag Duos in der Nähe seines Besitzers befindet.

Privatsphärenschutz

Nur du kannst den Standort deines SkyTag Duos sehen. Der SkyTag Duos speichert keine Standortdaten oder -verläufe physisch im Gerät. Alle Datenübertragungen im "Wo ist?"-Netzwerk sind anonym und verschlüsselt. Weder Apple noch andere Nutzer können die Identität oder den Standort von Geräten einsehen, die an der Suche beteiligt sind.

DE

5 Hinweise zur Bedienung unter Google Find Hub

Hinzufügen des SkyTag Duos zu Google Find Hub:

1. Stelle sicher, dass dein Android-Smartphone die neueste Version von Android 9 oder höher nutzt.
2. Aktiviere die Bluetooth- und Standortfunktionen deines Geräts, um eine Verbindung herzustellen.
3. Öffne die App "Mein Gerät finden" (Find My Device).
4. Tippe auf "Neues Gerät hinzufügen" oder "Tracker koppeln".
5. Schalte den SkyTag Duos durch kurzes Drücken des Ein-/Aus-Symbols auf der Vorderseite ein.
6. Halte den SkyTag Duos nahe an dein Smartphone (maximal 10 cm Abstand), damit er erkannt werden kann.
7. Es erscheint ein Pop-up-Fenster; verbinde das darin angezeigte "Air Device".
8. Folge den Anweisungen auf dem Bildschirm und bestätige die Kopplung.
9. Vergib einen Namen für deinen SkyTag Duos, damit du ihn in der App leichter identifizieren kannst.

Hinweis: Wenn das Pop-up-Fenster nicht erscheint, überprüfe bitte deine Internet-, und Wireless-verbindungen oder melde dich in der App ab und anschließend wieder an. Nach erfolgreicher Einrichtung erscheint dein SkyTag Duos in der Geräteübersicht der Find My Device-App.

Mit einem anderen Google-Konto koppeln

Wenn du den SkyTag Duos mit einem anderen Google-Konto verbinden möchtest, entferne ihn zuerst aus der Find My Device-App.

1. Öffne die App und wähle deinen SkyTag Duos aus.
 2. Tippe auf "Gerät entfernen".
 3. Halte anschließend die Taste fünfmal hintereinander gedrückt und beim fünften Mal etwa 5 Sekunden lang, bis ein Bestätigungston ertönt.
- Danach kannst du den SkyTag Duos mit einem anderen Google-Konto koppeln, indem du die obigen Schritte erneut ausführt.

Verloren-Modus aktivieren

Wenn du deinen SkyTag Duos verloren hast:

1. Öffne die Find My Device-App und wähle das betreffende Gerät aus.
 2. Aktiviere den Verloren-Modus und gib optional eine Telefonnummer oder E-Mail-Adresse an.
- Du erhältst automatisch eine Benachrichtigung, sobald dein SkyTag Duos von einem Gerät im Find My Device-Netzwerk geortet wird.

Schutz vor unerwünschtem Tracking

Dein Android-Gerät erkennt automatisch, wenn sich ein unbekannter Tracker über längere Zeit in deiner Nähe befindet. In diesem Fall erhältst du eine Warnmeldung. Wenn der SkyTag Duos weiter in deiner Nähe bleibt, wird ein akustisches Signal abgespielt, um dich zu warnen.

Privatsphärenschutz

Nur du kannst den Standort deines SkyTag Duos sehen. Der SkyTag Duos speichert keine Standortdaten lokal im Gerät. Alle Datenübertragungen über das Google Find My Device-Netzwerk sind verschlüsselt und anonymisiert. Weder Google noch andere Nutzer können die Identität oder den genauen Standort deines Trackers einsehen.

DE

6 Wartung und Pflege

- Öffne das Gerät nicht und lass es nur von einem Fachmann reparieren.
- Verwende zur Reinigung keine scharfen Chemikalien, Reinigungsmittel oder ähnliches.
- Verwende zum Abwischen ein sauberes, trockenes Stofftuch.
- Kontrolliere die Batterie regelmäßig und tausche sie ggf. aus, um eine dauerhafte Funktion zu gewährleisten.

7 Gewährleistung

Die 4smarts GmbH übernimmt keinerlei Haftung oder Gewährleistung für Schäden, die aus unsachgemäßer Installation, Montage und unsachgemäßem Gebrauch des Produktes oder einer Nichtbeachtung der Bedienungsanleitung und /oder der Sicherheitshinweise resultieren.

8 Hinweise zum Umweltschutz

 Elektrische und elektronische Geräte sowie Batterien dürfen nicht mit dem Hausmüll entsorgt werden. Verbraucher sind gesetzlich verpflichtet, diese am Ende ihrer Lebensdauer an öffentlichen Sammelstellen oder Verkaufsstellen abzugeben. Mit der Wiederverwertung und sachgerechten Entsorgung leistest du einen wichtigen Beitrag zum Umweltschutz.

9 Service und Support

Bei defekten Produkten oder Problemen während der Installation wende dich bitte an deinen Händler oder an die 4smarts Produktberatung auf: <http://www.4smarts.com/contact>

Service-Hotline
Montag –Freitag: 9 –17h
Tel.: + 49 (0)821 20708444
E-Mail: customer-service@4smarts.com

10 Konformitätshinweis

Hiermit erklärt die 4smarts GmbH, dass sich dieses Produkt in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 2014/53/EU befindet. Die Konformitätserklärung nach der RED Richtlinie findest du unter www.4smarts.com.

11 Hinweis EU Data Act:

Dieses Produkt generiert während der Nutzung Daten (z. B. Standort-, Sprach- oder Statusinformationen). Diese sind ausschließlich für den Nutzer zugänglich und dienen der Funktionsbereitstellung. Die Verarbeitung erfolgt im jeweiligen System, in der App oder auf dem Endgerät. 4smarts hat keinen Zugriff auf diese Daten.

DE

12 Hinweis zu Netzwerktechnologien und Markenrechten

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. To use the Apple Find My app to locate this item, the latest version of iOS, iPads, or macOS is recommended.

Use of the Works with Google Find My Device badge means that this product has been designed to work specifically with the Find My Device network and has been certified by the manufacturer to meet Google's network product specifications and requirements. Google is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Google, Android, and Find My Device are trademarks of Google LLC.

4smarts

Thanks for buying our product! We at 4smarts are sure it will serve you well. Follow us on social media for news, customer support and to win great prizes. See you there!



@4smarts_official



facebook.com/4smarts



linkedin.com/company/4smarts



All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.

541716 541717