



CAPTAIN240 EX
User manual



1 Heatsink set	1 pc	2 120mm Fan	2 pcs	3 Back Plate	1 pc	4 Screw Bolt	4 pcs	5 Fan Screw	8 pcs
6 Case Screw	8 pcs	7 Nut A	4 pcs	8 Nut B	4 pcs	9 Double-screw Bolt	4 pcs	10 Mounting Bracket(Intel)	2 pcs
11 Mounting Bracket(AMD)	2 pcs	12 Fan Hub	1 pc	13 3M Sticker	1 pc	14 Cable Tie	1 pc	15 Extension cable	1 pc

INTEL/AMD

INTEL
LGA1366
LGA1156
LGA1155
LGA1151
LGA1150
Installation

AMD
FM2+
FM2
FM1
AM4
AM3+
AM3
AM2+
AM2
Installation

INTEL
LGA2011
/2011-v3
Installation

INTEL/AMD

1. CPU FAN1/FAN2
2. Prior to CPU FAN1/FAN2/OPT, and then PWR/CHA/SYS FAN

Beijing Deepcool Industries Co., Ltd.
Beijing Deepcool Industries Co., Ltd.
Patent Pending
Devices and designs are trademarks from Beijing Deepcool Industries Co., Ltd.
All rights reserved.

www.gamertorm.com



船长240 EX
使用说明书



1 散热器主体	1 个	2 风扇	2 个	3 背板	1 个	4 螺柱	4 个	5 风扇螺丝	8 个
6 机箱螺丝	8 个	7 螺母A	4 个	8 螺母B	4 个	9 双头螺栓	4 个	10 Intel转接架	2 个
11 AMD转接架	2 个	12 风扇集线器	1 个	13 集线器胶贴	1 个	14 扎线带	1 个	15 风扇延长线	1 个

INTEL/AMD

INTEL
LGA1366
LGA1156
LGA1155
LGA1151
LGA1150
安装

AMD
FM2+
FM2
FM1
AM4
AM3+
AM3
AM2+
AM2
安装

INTEL
LGA2011
/2011-v3
安装

INTEL/AMD

1. 连接在CPU FAN1/FAN2
2. 连接在CPU FAN1/FAN2/OPT; PWR/CHA/SYS FAN均可

中国总部
地址：北京市昌平区科技园9号10号楼
北京九州风神科技股份有限公司
九州风神2011-2012年度最佳
产品奖获得者 | 2011-2012年度最佳
产品奖获得者 | 2011-2012年度最佳

www.gamertorm.com

