







# LCD Monitor Quick Start Guide

Business Monitor | BL Series

DN: BL81T-EQ-VI


© 2021 BenQ Corporation. All rights reserved. Rights of modification reserved.



USB 3.0 Upstream




Audio (optional)



HDMI (optional)





DVI (optional)



D-Sub (optional)



DP (optional)




(For models with HDMI inputs)




P/N: 4J.XXXXX.XXX

1




2




3



4




5



6 Video

7 Audio



8 USB




6 Video

7 Audio



8 USB




1




2



1




2




M4 x 10 mm


9



10



11



Support.BenQ.com



Online Manual



Product Support



Software Download